


HunterDouglas

Installation • Operation • Care



Pirouette® Window Shadings
EasyRise and UltraGlide Operating Systems
and Two-On-One Headrail Shadings

CONTENTS

GETTING STARTED

| | |
|----------------------------------|---|
| Product View..... | 1 |
| Tools and Fasteners Needed | 2 |

INSTALLATION

| | |
|---|----|
| Installation Overview..... | 3 |
| Mount the Installation Brackets — Inside Mount..... | 4 |
| Mount the Installation Brackets — Outside Mount | 6 |
| Mount the Installation Brackets — End Mount..... | 8 |
| Install the Shading..... | 9 |
| Attach the Dust Cover (Optional for Outside Mount)..... | 9 |
| Attach the Universal Cord Tensioner (UCT) — EasyRise™ Only..... | 10 |
| Attach the Wand — UltraGlide® Only..... | 10 |

OPERATION

| | |
|---|----|
| Operate the Shading | 12 |
| Attach Magnetic Hold-Down Brackets (Optional) | 14 |
| Troubleshooting | 15 |

CARE

| | |
|---------------------------|----|
| Removing the Shading..... | 18 |
| Cleaning Procedures | 18 |

CHILD SAFETY


| | |
|---------------|----|
| Warning | 20 |
|---------------|----|

| | |
|-----------------------|------------|
| WARRANTY | Back Cover |
|-----------------------|------------|

Questions?

Call Hunter Douglas Consumer Support at **1-888-501-8364**.

Product View



Not Shown: Two-On-One Headrail Shadings

GETTING STARTED

Thank you for purchasing Hunter Douglas Pirouette® Window Shadings. With proper installation, operation, and care, your new shadings will provide years of beauty and performance.

Please thoroughly review this instruction booklet and the enclosed packing list before beginning the installation. Leave the protective cover on the fabric-covered headrail until you are satisfied with the installation and operation of your shading.

IMPORTANT: An orange shipping clip is installed in the headrail for the UltraGlide® shading. Please do not remove the clip until instructed to do so.



Tools and Fasteners Needed

- Flat blade and Phillips screwdrivers
- Level (laser level is recommended)
- Measuring tape and pencil
- Pliers
- Power drill, $\frac{3}{32}$ " drill bit, and $\frac{1}{4}$ " hex driver
- Open end wrench, $\frac{5}{16}$ " (8 mm)
- Scissors (heavy-duty)

In addition, you will need fasteners designed to work with your specific mounting surface(s).

- **#6 Hex Head Screws (Provided).** Two $1\frac{1}{2}$ " screws are provided per installation bracket.
- **Longer #6 Hex Head Screws (Not Provided).** If using spacer blocks, use #6 screws long enough for a secure attachment.
- **Speed Nuts and Screws (Provided).** Extension brackets come with screws and speed nuts.
- **Drywall Anchors (Not Provided).** Use drywall anchors when mounting into drywall.



**#6 x 1 1/2"
Hex Head Screw
(Provided)**



**Longer #6 Hex Head Screw
for Use with Spacer Blocks
(Not Provided)**



**Speed Nut
and Screw
(Two Provided with
Each Extension Bracket)**

Installation Overview


- Your order will include the correct number of installation brackets for your shading width, as shown in the table below.
- Shading orders may also include spacer blocks or extension brackets, if they were specified for added clearance.
 - Extension brackets are used for end mount shadings, as well.

Installation Bracket





| Shading Width | Brackets |
|---------------------------|----------|
| 12" – 30" | 2 |
| 30 $\frac{1}{8}$ " – 60" | 3 |
| 60 $\frac{1}{8}$ " – 90" | 4 |
| 90 $\frac{1}{8}$ " – 120" | 5 |

For Added Clearance



Mounting Types and Window Terminology

If the installation brackets are mounted correctly, the rest of the installation process follows easily. To prepare for this important first step, review the mounting types and basic window terminology illustrated below.




- Refer to the appropriate page below based on your order:
 - **Inside Mount — Page 4**
 - **Outside Mount — Page 6**
 - **End Mount — Page 8**

INSTALLATION

Mount the Installation Brackets — Inside Mount


If Using the Optional Back Cover ...

- Remove the top tab on the back cover brackets.
- Snap each back cover bracket into a metal installation bracket.




Mount the Installation Brackets

- Mark 2" from each jamb for bracket location.
 - If more than two installation brackets came with your order, space additional bracket(s) evenly between the two end brackets and mark their location. Mount into wood whenever possible.



- **Two-On-One Headrail shadings:** Place installation brackets 3" on each side of the panel split, as shown below.



- Mark the location of the screw holes.
 - The minimum depth required for mounting is 1".
 - The fully recessed mounting depth is 3¾".
 - If using the optional back cover, an additional ¼" mounting depth is required.

IMPORTANT: The front edges of the installation brackets must be level and aligned to each other.



WARNING: Failure to properly align the brackets could result in the headrail releasing from the brackets.




- Use a level to check that the mounting surface is level. Shim the brackets, if necessary.
- Drill the screw holes using a 3/32" drill bit.
- Attach the installation brackets using the screws provided.

CAUTION: Use drywall anchors when mounting into drywall.

IMPORTANT: Do not overtighten the screws. Check to ensure the lever can be moved easily side to side. If not, loosen the screws in one-eighth turn increments until the lever can be moved easily.

Install the Optional Back Cover

- Install the cover into the back cover brackets.
- If necessary, trim the back cover to the desired width.




Proceed to "Install the Shading" on page 9.


INSTALLATION

Mount the Installation Brackets – Outside Mount

- Center the headrail over the window opening at the desired height. Use a pencil to lightly mark each end of the headrail.
 - Alternatively, measure the width of the headrail and use that width to mark the headrail end points over the window opening.
- Mark 2" from each end of the headrail.
 - If more than two installation brackets came with your order, space additional bracket(s) evenly between the two end brackets and mark their location. Mount into wood whenever possible.




- **Two-On-One Headrail shadings:** Place installation brackets 3" on each side of the panel split, as shown below.



- Center the installation brackets or extension brackets on your marks and mark the location of the screw holes.
 - A minimum 1" flat vertical surface is required for the installation brackets. Extension brackets require 1¼".
 - The tops of the installation brackets or extension brackets should be at the desired height. The brackets should be level and aligned.

CAUTION: The rear of the brackets must be flush against a flat mounting surface. Do not mount brackets on curved molding.




- Drill the screw holes using a 3/32" drill bit.

CAUTION: Use drywall anchors when mounting into drywall.

- Attach the installation or extension brackets using the screws provided.


IMPORTANT: The tops of the installation brackets or extension brackets must be level with their front edges aligned.



- If using spacer blocks, attach the spacer block(s) and installation bracket to a flat vertical mounting surface with #6 screws long enough for a secure installation.


IMPORTANT: Do not add more than 1½" of clearance using spacer blocks.

IMPORTANT: The tops of the installation brackets must be level with the front edges aligned.



INSTALLATION

- If using extension brackets, attach an installation bracket to the underside of each extension bracket using the speed nuts and screws provided.



Proceed to "Install the Shading" on page 9.

Mount the Installation Brackets — End Mount


End mount the headrail when conventional mounting techniques will not work — for example, in an arched window opening.

Mount the Extension and Installation Brackets

- Mount the extension brackets on a flat vertical surface at least 1½" wide.
- Attach the installation brackets to the extension brackets using the provided screws and speed nuts.




WARNING: To end mount shadings into a surface other than a secure wall stud, use medium to heavy-duty wall anchors (not provided) matched to the wall thickness. Failure to mount the brackets securely may result in injury or property damage.



Install the Optional Back Cover

- Remove the top tab on the back cover brackets. See "If Using the Optional Back Cover ..." on page 4.
- Install the cover into the back cover brackets.
- If necessary, trim the back cover to the desired width.




Proceed to "Install the Shading" on page 9.

Install the Shading

IMPORTANT: Leave the protective film on the fabric-covered headrail until you are satisfied with the installation of your shading.

- Position the shading so that the front faces you.
- Slide the headrail into the installation brackets so the edge of the headrail is between the lever and the bracket, as shown.
- Firmly push the headrail into each bracket until it clicks and the lever snaps to the right side of the bracket.




IMPORTANT: Carefully pull on the headrail at each bracket to ensure it is installed securely.

- Remove the protective film from the fabric-covered headrail.


Attach the Dust Cover (Optional for Outside Mount)

The dust cover is used to protect the top of the headrail from exposure on outside mounted shadings.

- Cut the dust cover to desired width.
- Remove the paper backing on one side of the hook and loop fastener dots.
- Apply the dots to the installation brackets on each end of the shading.




Overhead View — No Dust Cover



- Remove the remaining paper backing from the dots.
- Center the dust cover over the top of the shading, above the previously placed dots.
- Press the dust cover down onto the dots.

Dust Cover Installed




INSTALLATION

Attach the Universal Cord Tensioner (UCT) – EasyRise™ Only

IMPORTANT: Before you proceed, you must first slide the cord tensioner to the bottom of the cord loop.

- Insert a small screwdriver, punch, or awl through the screw hole at the bottom of the cord tensioner.
- Move the screw hole down to the indicator line to release the safety mechanism.
- Slide the cord tensioner down to the bottom of the cord loop.
- Attach the cord tensioner according to the instructions provided with the *Universal Cord Tensioner Installation Kit*.




WARNING: It is imperative that the cord tensioner be properly secured to the wall or window frame to reduce children's access to the cord loop. Young children can strangle in cord loops. They can also wrap cords around their necks and strangle.

CAUTION: The shading will not operate properly unless the cord tensioner is secured. A *Universal Cord Tensioner Installation Kit* has been included with your shading. Follow the instructions in the kit to correctly secure the cord tensioner.

Attach the Wand – UltraGlide® Only


The wand must be securely attached to the shading for proper operation.

- Remove the orange shipping clip.
 - Grab the edge of the shipping clip and pull straight down.




- Remove the wand from its packaging.

- Gently pull out the bumper and threaded connector until it is visible.



- Slide the bumper away from the threaded connector.


CAUTION: Do not grip the bumper on top of the connector and attempt to screw on the wand at this point. Secure attachment of the wand cannot be guaranteed if tightened by hand.



- Hold the threaded connector with a $\frac{5}{16}$ " (8 mm) open end wrench, and screw the hollow end of the wand onto the threaded connector, as shown. If necessary, pliers can be used instead of a wrench.

➤ Continue to firmly rotate the wand until you feel it click two times and the wand stops moving. This ensures the wand is securely attached.


CAUTION: If the wand is not properly secured, it will come loose after repeated use.




- Slide the bumper back onto the threaded connector.

➤ Make sure the bumper is properly aligned and seated tightly on top of the threaded connector.

NOTE: The underside of the bumper matches the shape on the top of the threaded connector.



- Gently release the wand.



OPERATION

Operate the Shading

Important Operating Note


If a shading has been fully lowered with the vanes open for a long period of time, the vanes may become “set” — they may not easily close or flatten. This is a normal characteristic of fabric products.

If this happens, move the shading up and down to coax the vanes as closed as possible. If necessary, gently pull down on the lowest operable vane. You may also dress the vanes gently with your hands to help them close. Then roll up the shading slowly to flatten the vanes. Allow the fabric to remain in the headrail for up to 24 hours.

To prevent vane set, regularly “exercise” the shading by raising and lowering it and opening and closing the vanes.

EasyRise™ Shadings

- Pull the front or rear cord to raise or lower the shading. The shading will hold its position when you release the cord.
 - **To lower the shading:** Pull down on the rear cord of the cord loop (indicated by the white arrow).
 - With the shading fully lowered, continue to pull the rear cord to open the vanes.
 - **To raise the shading:** With the shading fully lowered, pull down on the front cord of the cord loop (indicated by the white arrow).



IMPORTANT: If the cord tensioner moves up the cord, you have not secured it to the wall or window casement. You must do so for the shading to operate properly. See “Attach the Universal Cord Tensioner (UCT) — EasyRise™ Only” on page 10.

Two-On-One Headrail EasyRise Shadings

- Two-On-One Headrail shadings have two cord loops. The right cord loop operates the right shading and the left cord loop operates the left shading.

IMPORTANT: With Two-On-One Headrail shadings, both cord tensioners must be properly secured to the wall or window casement for the shading to operate correctly.

UltraGlide® Shadings

To Lower the Shading

- Pull the wand straight out from the fabric at an angle greater than 25 degrees. The clutch will click and the fabric will proceed with a controlled descent.
- To stop the shading in any position, simply pull the wand straight down.

IMPORTANT: Avoid pulling the wand in the non-operable zone. This is the area between the angle for lowering the shading and the straight down position for raising the shading. Refer to the illustration below.


To Open the Vanes

- After lowering the shading completely, continue to pull on the wand at an angle greater than 25 degrees, until the vanes are fully open.

To Close the Vanes and Raise the Shading

- Hold the wand close to the fabric and pull straight down.
- Pump the wand down using short strokes to gradually raise the shading.

CAUTION: To avoid damage to the shading or personal injury, do not release the wand until it is fully retracted. To avoid breaking the wand, do not use long strokes (over 42") and apply excessive force on the wand while pulling it.




Two-On-One Headrail UltraGlide Shadings

- Two-On-One Headrail shadings have two wands. The right wand operates the right shading and the left wand operates the left shading.

OPERATION

Attach Magnetic Hold-Down Brackets (Optional)

- Lower the shading, keeping the vanes closed.
- Place the magnetic hold-down brackets onto the bottom rail just inside the end caps, oriented as shown.
- Hold the brackets while opening and closing the vanes. (It may be necessary to have someone assist you.) Adjust the brackets to the best overall position.
- Mark the screw locations using one of the mounting options shown below.
 - The screw should be placed in the middle of the channel to allow for adjustment.



Outside Mount



Preferred



Alternate

Inside Mount




Preferred




Alternate




- Drill the screw holes using a $\frac{3}{32}$ " drill bit.
- Attach the hold-down brackets to the mounting surface using the screws provided.
- If necessary, adjust the bracket height by loosening the screw and sliding the bracket up or down.



Troubleshooting

| | |
|-----------------|--|
| Problem | The shading will not snap into the installation brackets. |
| Solution | Check that the installation brackets are level. Shim to level, if necessary. Check that the headrail is completely inserted into the installation brackets. See "Install the Shading" on page 9. |
| Problem | The EasyRise™ cord tensioner has climbed to the headrail. |
| Solution | <p>Pull down on the spring to relieve tension and pull the cord tensioner to the bottom of the cord loop. Then properly mount the cord tensioner. See "Attach the Universal Cord Tensioner (UCT) — EasyRise™ Only" on page 10 and/or the instructions included with your <i>Universal Cord Tensioner Installation Kit</i>.</p>  |
| Problem | The EasyRise cord tensioner grabs onto the cord when the cord is pulled. |
| Solution | Check that the universal cord tensioner is mounted properly. Reinstall, if necessary. |
| Problem | The shading is hard to raise or lower, or will not raise or lower. |
| Solution | <p>Check that there is clearance between the ends of the shading and the window casement on inside mounts.</p> <p>Check that the universal cord tensioner is mounted properly. Reinstall, if necessary.</p> <p>Check that the installation brackets are level. Shim to level, if necessary.</p> <p>Check if the fabric rolls up evenly into the headrail. If not, see "Adjusting the Bottom Rail Weight" on page 16.</p> <p>If hold-down brackets are used, make sure they have been released.</p> |

OPERATION

| | |
|------------------------|---|
| <p>Problem</p> | <p>The shading raises or lowers unevenly, the bottom rail is not level when fully raised, or the fabric winds unevenly or starts to rub against one end of the headrail.</p> |
| <p>Solution</p> | <p>Check that the installation brackets are level. Shim to level, if necessary.</p> <p>Check if the window is out-of-square by measuring the diagonals. Shim the installation brackets to level, if necessary.</p> <p>If the headrail is level and the window is square, adjust the bottom rail weight.</p> <p>Adjusting the Bottom Rail Weight</p> <p>IMPORTANT: Only adjust the bottom rail weight if the fabric does not roll up straight into the headrail.</p> <p>First, release both weight locks. On the back of the bottom rail, insert a flat blade screwdriver into the slot in each weight lock and rotate the lock up, toward the center of the rail.</p>  <p>Slide the weight, in 1" increments, in the direction the fabric is gathering.</p>  <p>Test and, if necessary, adjust again.</p> <p>After final adjustment, rotate each lock down toward the outside of the rail to secure the weight. At least 1" should overhang each lock.</p>  |

| | |
|-----------------|---|
| Problem | The vanes will not open when the shading is first operated. |
| Solution | Open and close the shading quickly to help open the vanes. If necessary, gently pull down on the bottom rail. |
| Problem | The vanes do not close completely. They stay contoured and do not flatten. |
| Solution | <p>Use the cord or wand to open and close the vanes quickly. Coax the vanes as closed as possible. If necessary, gently pull down on the bottom rail. You may also gently dress the vanes with your hands to help them close. Then roll up the shading slowly to flatten the vanes. Allow the fabric to remain in the headrail for up to 24 hours.</p> <p>To avoid this in the future, regularly “exercise” the shading by raising and lowering it and opening and closing the vanes.</p> |

CARE



Removing the Shading

- Fully raise the shading.
- Move each lever of the installation brackets to the left to release the shading.
 - A flat blade screwdriver can be used to move the lever.

CAUTION: Be very careful not to tear or damage any of the fabric.

- If the lever is inaccessible or inoperable, lower the shading until you can see the underside of the bracket. Carefully reach a small flat blade screwdriver behind the shading to the tab on bottom of the bracket between the screw holes.
- Push the tab away from the shading and pull the headrail to release it from the bracket.

- Carefully pull the shading to remove it from the brackets.



Cleaning Procedures

Pirouette® Window Shadings are made of 100% polyester, which means they are inherently durable and resilient. However, care must be taken to avoid wrinkling the fabric, particularly where the vanes meet the sheer backing fabric.

CAUTION: Do not steam Pirouette fabrics.

Fabric-Covered Headrail

- Lightly dust with a clean, dry cloth, vacuum using low suction, or spot clean with a damp cloth and mild detergent.

Dusting

- Regular light dusting with a feather duster is all the cleaning needed in most circumstances.

Vacuuming

- Use a hand-held vacuum with low suction for more thorough dust removal.

Compressed Air

- Use compressed air to blow dust and dirt off shadings.

Spot Cleaning

- Spot clean with a damp cloth using a mixture of water and mild detergent.

Injection/Extraction

- Most Pirouette® Window Shadings can be professionally cleaned using the injection/extraction method.

Ultrasonic Cleaning

CAUTION: Do not ultrasonically clean India Silk, Satin Metallic, or Shantung fabrics.

- Other Pirouette fabrics can be ultrasonically cleaned by a professional.
- Specify that a mild detergent solution be used.
- Never immerse the headrail in the solution.
- Allow the shading to dry in the completely lowered position.


Electrostatic Cleaning

- Do not use electrostatic cleaning devices on any Pirouette Window Shading.

A Note About Pirouette Fabric

As with all textiles, Pirouette fabrics are subject to some variations. Slight wrinkling, puckering, or bowing is inherent to this textile product and should be considered normal, acceptable quality. These characteristics are not usually visible from the front or rear but may be visible from a side angle.

Precautions should be taken to reduce exposure to harsh environmental elements, such as salt air. Continuous exposure through open windows and doors will accelerate the fabric deterioration.




WARNING

- **Window Blind Cord Can STRANGLE Your Child.**
- **Children can climb furniture to reach cords. Move crib and furniture away.**
- **Keep all cords out of children's reach.**

Cord Loop Shadings

- **Attach the cord tensioner on the cord loop to the wall or window casement. See "Attach the Universal Cord Tensioner (UCT) — EasyRise™ Only" on page 10. This can prevent children from pulling cord loops around their necks.**
- **Hunter Douglas provides a cord tensioner installation kit with instructions for attaching the cord tensioner. For the shading to operate properly, the cord tensioner must be correctly mounted and secured.**
- **Fasteners provided in the cord tensioner installation kit may not be appropriate for all mounting surfaces. Use appropriate anchors for the mounting surface conditions.**
- **Only Hunter Douglas supplied cord tensioners and hardware should be used. Replacement parts may be obtained by contacting Hunter Douglas Consumer Support at 1-888-501-8364.**



NOTE: The warning labels on the bottom rails of corded window coverings contain important safety information. These warning labels are designed to be permanent, in accordance with the industry's safety standards, and must not be removed.

LIFETIME GUARANTEE

The Hunter Douglas® Lifetime Guarantee is an expression of our desire to provide a thoroughly satisfying experience when selecting, purchasing and living with your window fashion products. If you are not thoroughly satisfied, simply contact Hunter Douglas at (888) 501-8364 or visit hunterdouglas.com. In support of this policy of consumer satisfaction, we offer our Lifetime Limited Warranty as described below.

COVERED

BY A LIFETIME LIMITED WARRANTY

- Hunter Douglas window fashion products are covered for defects in materials, workmanship or failure to operate for as long as the original retail purchaser owns the product (unless shorter periods are provided below).
- All internal mechanisms.
- Components and brackets.
- Fabric delamination.
- Operational cords for a full 7 years from the date of purchase.
- Repairs and/or replacements will be made with like or similar parts or products.
- Hunter Douglas motorization components are covered for 5 years from the date of purchase.

Hunter Douglas (or its licensed fabricator/distributor) will repair or replace the window fashion product or components found to be defective.

NOT COVERED

BY A LIFETIME LIMITED WARRANTY

- Any conditions caused by normal wear and tear.
- Abuse, accidents, misuse or alterations to the product.
- Exposure to the elements (sun damage, wind, water/moisture) and discoloration or fading over time.
- Failure to follow our instructions with respect to measurement, proper installation, cleaning or maintenance.
- Shipping charges, cost of removal and reinstallation.

TO OBTAIN WARRANTY SERVICE

1. Contact your original dealer (place of purchase) for warranty assistance.
2. Visit hunterdouglas.com for additional warranty information, frequently asked questions and access to service locations.
3. Contact Hunter Douglas at (888) 501-8364 for technical support, certain parts free of charge, for assistance in obtaining warranty service or for further explanation of our warranty.

NOTE: In no event shall Hunter Douglas or its licensed fabricators/distributors be liable or responsible for incidental or consequential damages or for any other indirect damage, loss, cost or expense. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Different warranty periods and terms apply for commercial products and applications.

HunterDouglas



hunterdouglas.com

QTY: 1

1003042



5/19

